


From:
EXP AIR →

PEEP
pressure
i.e., 5cmH₂O



To evacuation or scrubber
DO NOT connect directly to a vacuum source!
Expired air must flow freely from this port.

OPTIONAL:
PEEP setup
(Submerge EXP AIR tubing
under column of water)